

Gared Sports Model NCE Glue On Cushion Edge

Mounting Instructions

Unpack Cushion Edge and allow to lay flat at room temperature for at least 24 hours before installation.

1. Prepare the backboard frame for installation of the cushion edge as follows:
 - a. Scrape loose paint, dirt, or particles from the frame along the entire lower frame section and 13" up each side frame.
 - b. Further clean prepared area with sand paper or steel wool.
 - c. Wipe area with clean cloth saturated with paint thinner or mineral spirits.
2. Hold the cushion edge in the location it will be installed on the backboard and accomplish the following
 - a. Press firmly to imprint location of any bolt heads.
 - b. Mark the cushion edge with pen or pencil at any area that may come into contact with mounting brackets.
 - c. Using a hack saw, razor blade, or a sharp utility knife, trim away the areas marked for interference. Note: trim only enough away to allow for firm contact of the flat surfaces of the cushion edge.
 - d. Using a razor blade or sharp utility knife, trim away imprinted areas to bolt head depth to allow the flat surface of the cushion edge to adhere tightly.
3. Apply adhesive to the cushion edge as follows:
 - a. Apply adhesive sparingly to the inside of the pad making sure an even coat is applied to all surfaces. Apply adhesive to the bottom of the board and up 13" on each side. Allow the contact cement to set and become tacky.
4. Wait approximately 20 to 30 minutes to make sure the cement has become tacky. Apply the Cushion Edge to the bottom of the frame first and then push the on the sides. Apply pressure to all areas to insure cement has made full contact.

