

## Gared Sports Model PMCE Pro Mold Bolt On Cushion Edge

### Carton Contents


Quantity	Item description
4	Molded L-Pads
16	1/4-20 x 3" Bolts
16	1/4-20 x 1" Bolts
16	1/4-20 Locknuts

### Tools Required


Portable drill with a 5/16" drill bit  
Tape Measure  
Center Punch  
Utility Knife  
Masking Tape  
Marker

### Mounting Instructions

1. The L-Pads are Symmetrical so that any two pads will form a backboard kit.  
Note: For backboards that have been pre-drilled for PMCE, skip to step 7
2. Using the tape measure, mark the center of the backboard. Place one of the L-pads into position on the backboard and align the end of the pad to the center mark on the backboard. Use the masking tape to hold the L-pad in position while locating the holes.
3. Place the second L-pad into position and secure with masking tape. It may be necessary to trim the second pad under the rim for proper fit.
4. Using the marker, mark the locations for all holes to be drilled. **Always use the rear of the backboard to avoid drilling into the glass on the board.**
5. Remove the masking tape and L-Pads. Mark the center of each hole with the center punch.
6. Drill each hole with the 5/16" drill. Be sure to clean up any metal shavings to prevent damaging the floor.
7. Select the 1" or 3" bolts (depending on your backboard thickness) and bolt the first L-Pad in place. Making sure the end of the pad is aligned with the center mark on the backboard. Place the second pad in place against the end of the first pad and bolt into place.



**IMPORTANT!**  
Use rear mounting holes only. Using the front holes will damage your backboard.



[www.garedsports.com](http://www.garedsports.com)



[www.perfsports.com](http://www.perfsports.com)

Gared Holdings, LLC  
9200 East 146<sup>th</sup> Street, Suite A  
Noblesville, Indiana 46060

800-325-2682